

Pump Tubes – SP-PPS Series Spare Parts

SP-PPS Spare Parts		Ref #	Description	Part Number	Qty
	1	Hand Wheel	1842	1	
	2*	Pump Coupling	1004	1	
	3	Snap Ring	1508	1	
	4*	Bearing Unit, Assembly	1038	1	
	5	V-Seal, Viton	1000	1	
	6	Drive Shaft		1	
		27" (700 mm)	2027		
		39" (1000 mm)	2028		
		47" (1200 mm)	2029		
		60" (1500 mm)	2709		
		72" (1800 mm)	2033		
	7	Guide Sleeve, PTFE		1	
		27" (700 mm)	1516		
		39" (1000 mm), 47" (1200 mm), 50" (1270 mm)	1514		
		60" (1500 mm), 72" (1800 mm)	1661		
8	Discharge Housing	1028	1		
9	Wing Nut	1106	1		
10	Hose Barb		1		
	.75" (19 mm)	1051			
	1" (25 mm)	1082			
11	Inner Tube		1		
	27" (700 mm)	1600			
	39" (1000 mm)	1601			
	47" (1200 mm)	1602			
	50" (1270 mm)	1623			
	60" (1500 mm)	1615			
	72" (1800 mm)	1616			
12	Outer Tube		1		
	27" (700 mm)	1604			
	39" (1000 mm)	1603			
	47" (1200 mm)	1605			
	50" (1270 mm)	1624			
	60" (1500 mm)	1617			
	72" (1800 mm)	1618			
13*	Pump Housing (Includes Carbon Bushing)	1524	1		
14*	Rotor/Impeller		1		
	High Volume Rotor	1608			
	High Pressure Impeller	4608HH			
15*	Pump Foot		1		
	High Volume	1609			
	High Pressure	1609HH			
	Repair Kit* (Includes 2, 5 (4), 13, 14 & 15)	9050	1		

⚠ Warning: Not suitable for pumping flammable or combustible liquids or for use in a hazardous duty environment.